

# PowerChute™ Business Edition JRE Configuration Tool version 1.0.0.11 for Windows and Linux

## Introduction

The JRE Configuration Tool enables you to change the Java Runtime Environment (JRE) used by the PowerChute Server and Agent components to any other JRE already installed on your system.

For further background information, please see the APC Knowledge Base at <http://www.apc.com/site/support/index.cfm/faq/>: type **FA159623** as the FAQ ID.

**Important:** You must have administrator rights to install and run the JRE Config Tool.

## Contents

Introduction.....	1
Supported Operating Systems.....	1
Supported PowerChute Business Edition versions.....	1
Supported JRE versions.....	1
Running on Windows.....	2
Running the Tool on Windows without User Interaction.....	2
Running on Linux or Solaris.....	3
Running the Tool on Linux or Solaris without User Interaction.....	3
Further Notes.....	4
Windows.....	4
Linux and Solaris.....	4

## Supported Operating Systems

Any Microsoft® Windows®, Linux®, or Solaris® operating system supported by the PowerChute versions listed below.

## Supported PowerChute Business Edition versions

- PowerChute v7.0.4 and higher
- PowerChute v7.0.3 (supported on Windows NT only)

## Supported JRE versions

The JRE versions supported with the latest release of PowerChute are posted on the APC Web site at <http://www.apc.com/wp/?um=100>.

JRE 6 and JRE 7 are not supported for any version of PowerChute Business Edition under v9.0.

PowerChute Business Edition v9.0 and above supports JRE versions 6, 7 and 8.

You must install a supported version of JRE before running the JRE Config Tool.

## Running on Windows

Running the JRE Config Tool interactively:

1. Download the self-extracting Exe file called **PcbeJreConfigTool.exe** to a folder on your machine.  
The file can be found by going to <http://www.apc.com/tools/download/index.cfm> and choosing **Software Upgrades - PowerChute Business Edition** from the **Filter By Software / Firmware** drop-down box, clicking Submit and then looking for **JRE Configuration Tool**.
2. Extract the Exe file contents to a folder of your choice. (The default folder location is: "c:\PcbeJreConfigTool").
3. Double-click the extracted file called **PcbeJreConfig.exe**. (On Windows Vista, 7, 8, when UAC is enabled you must right-click the file and select "Run as administrator").  
The Tool displays the current version of JRE that PowerChute uses and the JREs available on your system.
4. Select an available JRE and click the **Change JRE** button to make the change.
5. Click the **Exit** button to finish.

### Description of Screen Buttons

<b>Refresh</b>	Display the latest information about the current JREs on your system.
<b>Change JRE</b>	Change the JRE used by PowerChute to the JRE you selected from "Available JRE(s) on this system".
<b>Exit</b>	Close the JRE Config Tool after saving the content displayed in the "Status" box as "PcbeJreConfig.log" to the user's TEMP folder.

### Running the Tool on Windows without User Interaction

The JRE Config Tool runs without user interaction if a file named **PcbeJreConfig.ini** with appropriate values is present in the same directory as **PcbeJreConfig.exe**. This changes the PowerChute JRE usage, saves the log and exits. It can also delete the old JRE.

When the JRE Config Tool is running in this mode, **Silent Mode** is displayed above the Refresh button. (While the JRE Config Tool is running, you can click the Exit button but the JRE Config Tool will run to completion before you exit).

The content displayed in the **Status** box is saved as **PcbeJreConfig.log** to the user's TEMP directory.

You can specify the following parameter in the JRE\_CONFIG section of the **PcbeJreConfig.ini** file:

**JRE\_PATH** The full path and name of the JRE that you want PowerChute to use.

For example:  
[JRE\_CONFIG]  
JRE\_PATH="C:\Program Files\Java\jre1.7.0\_13"

## Running on Linux or Solaris

Running the JRE Config Tool interactively:

1. Download a tar file called **pcbeJreConfigTool.tar** to a directory on your machine.

The file can be found by going to <http://www.apc.com/tools/download/index.cfm> and choosing **Software Upgrades - PowerChute Business Edition** from the **Filter By Software / Firmware** drop-down box, clicking Submit, and then looking for **JRE Configuration Tool**.

2. Extract the single file, **PcbeJreConfig.sh**, and execute it.

Type appropriate responses for each prompt.

## Running the Tool on Linux or Solaris without User Interaction

You can execute the JRE Config Tool silently by using the `-j` option when you run the tool.

Type the following command:

```
PcbeJreConfig.sh -j <the absolute path of the JRE and the name of the JRE>
```

For example,

```
#!/PcbeJreConfig.sh -j /opt/APC/jre/jre150_11
```

## Further Notes

If you install or upgrade either a PowerChute Server or Agent component after the JRE Config Tool has been run, you must re-run the Tool to change the JRE used by PowerChute.

## Windows

- The JRE Config Tool will time out if the PowerChute Server and Agent services cannot be stopped or started within two minutes. (These services need to be stopped in order to change the JRE).
- You cannot exit the tool while the change is taking place (this takes up to four and half minutes to complete).
- If the JRE Config Tool has a problem with updating an unsupported JRE or if service fails to start, it either blocks the update or rolls back to your previous JRE.
- Once you run the tool successfully, if you subsequently uninstall PowerChute you will need to remove some files and folders manually.

Check for the default folder called *<drive letter>\program files\APC\PowerChute Business Edition* or the non-default folder you had specified during the installation (e.g. *c:\apc*) and delete it, including its contents, if it still exists.

If PowerChute is the only APC product installed, you can also delete the APC folder.

- The Windows' TEMP directory is a hidden folder and you cannot see the **PcbeJreConfig.log** file located there unless you change the default Windows view option.

Follow these steps to change the default option. 1) Open Explorer. 2) Click "Tools". 3) Click either "Folder Options" or "Options". 4) Click the "View" tab. 5) Select "Show hidden files and folders".

- When you run the Tool in Silent Mode, on very rare occasions a dialog displays stating "PcbeJreConfig has stopped working". This has no effect and the JRE change has already occurred. Click "Close the program" to continue.

## Linux and Solaris

- PowerChute will not operate correctly if you uninstall the JRE that it uses.  
If you have to uninstall the JRE, first change the PowerChute JRE usage (using the JRE Config Tool).
- If the shell script (.sh) does not execute, you might need to change the file permissions by first using the command:  

```
chmod a+x PcbeJreConfig.sh
```
- The JRE that was previously used by PowerChute is not removed because it might be in use by other applications. You can remove it manually after you confirm that no other product on your system is using it.

